



# CHD5101

## ASSEMBLY & INSTALLATION GUIDE

CORD COVER  
MOUNTING OPTION  
(Fig. 1)



DIRECT WIRE  
MOUNTING PLATE  
(Fig. 2)



**INSPECT ITEM CAREFULLY BEFORE ATTEMPTING TO INSTALL. IF THERE IS ANY DAMAGE OR OBVIOUS DEFECT, DO NOT INSTALL.**

**ITEM MAY NOT BE RETURNED ONCE IT HAS BEEN INSTALLED.**

1. **\*\*\*CORD COVER ASSEMBLY\*\*\*** (See Fig. 1)

1. Remove all parts carefully from the box.
2. Screw threaded nipple of cord cover (D) into bottom threaded opening of back plate (C). Thread cord cover (E) into cord cover (D), thread cord cover (F) to cord cover (E) and band tighten.
3. Measure center points between both mounting holes at back of fixture base (C). Mark two points with same distance on the wall, make sure they are vertical with each other.
4. Drill small holes at both points, hole should be big enough to accommodate plastic anchors (A). Insert plastic anchors (A) in these holes.
5. Thread mounting screws (B) into plastic anchors (A), do not fully tighten.
6. Hook fixture base (C) onto both screws (B).
7. Insert harp (K) into harp saddle (J) by squeezing both sides of the harp.
8. Remove finial (L) from harp (K). Place lamp shade (not included) over the bolt attached on top of harp (K), screw finial (L) onto the bolt to secure lamp shade to the harp.
9. Insert light bulb into socket. Remove plastic cover (H) from plug (G). Plug lamp into wall outlet.

2. **\*\*\*DIRECT WIRE INSTALLATION\*\*\*** (See Fig. 2)

We strongly recommend installation by a professional electrician

1. Follow step 1 of CORD COVER ASSEMBLY.
2. Guide wiring from wall outlet through center hole in mounting plate (M). Affix mounting plate (M) to wall outlet box with mounting screws (N) provided.
3. Cut fixture cord twelve inches away from fixture base (C) and remove by grasping plug (G) and pulling out of cord cover (D, E & F).
4. Connect the ground screw (green color) of the fixture to the bare copper ground wire in the outlet box. The insulation on the fixture cord that was cut to twelve inches in length in step 3 has a smooth side and a ribbed side. Connect the smooth wire to the black wire in the outlet box (not shown in diagram). Connect the ribbed wire to the white wire in the outlet box.
5. Attach fixture base (C) to the affixed mounting plate (M), and secure with base screws (O).
6. Follow steps 7, 8 & 9 of CORD COVER ASSEMBLY.